























































Assembly (all = R-30)	Vented?	Vapour Control	Air Control
Unvented Closed Cell	No	CCSPF	SPF
Vented Closed Cell	Yes	CCSPF	SPF
Vented Fiberglass	Yes	latex paint on drywall	Drywall
Unvented Open Cell w/ Paint	No	paint on foam and drywall	SPF
Unvented Open Cell	No	latex paint on drywall	SPF
Vented Open Cell	Yes	latex paint on drywall	SPF





	Vancouve				ver	1	Foront	0	Ottawa				
Cathedral Roof Construction				HDD 3000			HDD 4000			HDD 4500		00	
Co	ntents of Cavity	Depth of Cavity	Ventilation	Type of Vapour Control	Low RH 30/55%	Med. RH 40/60%	High RH 50%	Low RH 30/55%	Med. RH 40/60%	High RH 50%	Low RH 30/55%	Med. RH 40/60%	High RH 50%
ne Foam (SPF)	2.0 pcf Closed Cell <sup>3</sup>	5" R30	Ventilated Continuous Baffle	ccSPF	13%	13%	13%	10%	10%	10%	10%	10%	10%
		5" R30	Non-ventilated	ccSPF	11%	14%	14%	10%	13%	13%	12%	14%	14%
	0.5 pcf Open Cell	8" R30	Non-ventilated	interior poly	13%	13%	13%	13%	13%	13%	13%	14%	15%
olyuretha		8" R30	Ventilated	latex paint	13%	13%	14%	11%	11%	11%	11%	11%	11%
Spray P		8" R30	Non-ventilated	1 US perm paint on foam	12%	17%	18%	13%	24%	28%	15%	30%	32%
		8" R30	Non-ventilated	latex paint	17%	30%	35%	25%	40%	50%	38%	52%	54%
Fit	berglass	9 1/4" R30	Ventilated Continuous Baffle	interior poly									
	Batt	9 1/4" R30	Ventilated Continuous Baffle	latex paint	16%	17%	17%	14%	14%	14%	13%	13%	13%
	Other Applicable Locations (Heating Degree Days below 18°C)			White Rock (2782) Vancouver (2926) Abbotsford (2981) Victoria (3040)			Windsor (3524) Niagara Falls (3661) Kelowna (3869) Oshawa (3917) Hamilton (4012)			Kitchener-Waterloo (4288) Kingston (4289) Montréal (4518) Moncton (4585)			
							Halifax (4030) London (4057) Toronto (4065)			Ottawa (4602) Charlottetown (4715)			



























## Intro to the Guide

- $\rightarrow$  Introduction & Background
  - → Building Enclosure Fundamentals
  - $\rightarrow$  R-Value Calculation
  - $\rightarrow$  Effective R-value of Tapered Insulation
  - $\rightarrow$  Vaulted Roofs
  - $\rightarrow$  Low-slope Roofs
- $\rightarrow$  Spray Foam in Roofs
- → Roof Decks
- → Airtightness
- $\rightarrow$  Alternative R-30 Roofs
- → Maintenance & Inspection
- $\rightarrow$  Summary

R30+ Effective Vaulted & Flat Roofs in Residential Construction In British Columbia







## <section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><image><section-header>





